MVR user guide

Once the MVR software has been downloaded and the installation is complete connect your eVic to the USB port and the following interface will be displayed:



Only Charging: The eVic will charge only and the MVR software will not open.

See my Vapor Record: The MVR software will open and the eVic will also still charge.

Connect eVic: Get data from e-cig: this will import and save your vaping diagnostics into MVR

Upgrade my e-Cig: upgrade the software of your eVic, once upgrades are installed disconnect the eVic to complete the upgrade.

Vapor Set:

Switch: This allows you to configure the settings for **VV, VW, MVR VV** and **MVR VW** by selecting from the drop down box which output you want to modify.

VV (variable voltage) set the voltage of your device
VW (variable wattage) set the wattage of your device

MVR VV: Will display the following interface:



Connect eVic: Get data from e-cig: this will import and save your vaping diagnostics into MVR

Upgrade my e-Cig: upgrade the software of your eVic, once upgrades are installed disconnect the eVic to complete the upgrade.

Vapor set continued

Mode: Change the button on your eVic from manual to semi-automatic

Auto: The device will activate for the pre-set number of seconds with just one press of the button. Pre-set time can be up to 9.9 seconds.

HomeScr: Select what you would like displayed in the top left corner of the home screen.

Puff Count: Will display the number of inhalations taken on the device and the remaining inhalations left at current voltage.

Date Time: Will display the current date and time

V/W ohms: Will display the current Voltage/Wattage being used and the resistance (ohms) of the atomizer attached.

Puff set: Daily max- limit the number of inhalations you can take in one day

Reset Puff: Once the daily number of inhalations reaches this number the Daily counter will reset to 0.

Total Puff: Number of inhalations in total taken on the device since set up.

Configuration: The following interface will display:



Configuration

General:

Battery: Select the mAh of the battery currently being used in order for the battery percentage indicator to be accurate.

Screen: Use the pre-set times or customize your own for the screen to shut down.

System: Use the pre-set times or customize your own to shut down the system if there is no user activivity for the set period of time.

Temp C: Displays the current temperature of the device and gives you the option to customize the temperature at which the alarm indicator will display on the eVic home screen.

Calender:

Set an accurate date and time for MVR and the eVic.

Device Info: The following interface will display:



General: Displays your unique device I.D. Battery remaining, atomizer resistance and the current software version installed.

User info: Personalise the user information on your eVic with your name, age and gender.

PLEASE NOTE: To save any changes made in MVR to your eVic device you need to click Modify after each amendment.

myVapors:

In my vapors you can see all of your vaping statistics for a daily, weekly or monthly period of time.

Wattage: shows the number of inhalations taken at a range of wattage outputs.

Voltage: shows the number of inhalations taken at range of voltage outputs.

Puffs: Shows the number of inhalations taken over a selected period of time.

Resistance: Shows how many inhalations have been taken at a specific atomizer resistance.



An average is also given for the daily, weekly or monthly diagnostics for each output option selected.

The bottom right columns show the statistics of inhalations taken whist in **MVR VV** and **MVR VW** mode.

All of this data can be exported in to an Excel spread sheet by clicking the **Export** button.

Closing the MVR window:

EXIT: Will close the MVR software completely

Close the window: Will close the current window but keep the MVR software in operation.